

GSM18B series





Features

- · Universal AC input / Full range
- 2 pole AC inlet IEC320-C8
- Medical safety approved (2 × MOPP between primary to secondary)
- Suitable for BF application with appropriate system consideration
- Low leakage current <50µA
- No load power consumption<0.1W
- Energy efficiency Level VI(except 5~9V for Level V)
- Comply with EISA 2007/DoE,NRCan,AU/NZ MEPS,EU ErP and meet CoC Version 5
- High efficiency up to 88%
- High operating temperature up to $+60^{\circ}C$
- Class II power (without earth pin)
- · Protections: Short circuit / Overload / Over voltage
- · Fully enclosed plastic case
- · LED indicator for power on
- Optional lock type DC plug
- · 100% full load burn-in test
- · 3 years warranty

Description

GSM18B is a highly reliable, 18W desktop style single-output green medical adaptor series. This product is equipped with a 2-pin (no FG) standard IEC320-C8 power plug, adopting the input range from 80VAC to 264VAC. The entire series supplies different output voltages between 5VDC and 48VDC that can satisfy the demands for various kinds of miniature medical devices. The circuitry design meets the international medical standards ($2 \times MOPP$), having an ultra low leakage current ($<50\mu A$), fitting the medical devices in direct electrical contact with the patients.

With the efficiency up to 88% and the extreme low no-load power consumption below 0.1W, GSM18B is compliant with USA EISA 2007/DoE, Canada NRCan, Australia and New Zealand MEPS, EU ErP and meet Code of Conduct(CoC) Version 5; the supreme feature allows the adaptor to save the energy when it is either under the operating mode or the standby mode. The entire series utilizes the 94V-0 flame retardant plastic case, providing the double insulation that effectively prevents electrical shock. GSM18B is approved with the international medical safety certificates.

Model Encoding GSM18 B 05 - P1J

- DC plug type $\begin{cases} P1J : Plug \text{ for standard model, } 2.1\psi \times 2.5\psi \times 11\text{ mm, c+, tuning fork type} \\ Optional plug type available by customer requested \\ - Output voltage \end{cases}$

Output voltage IEC320-C8 2 pin AC inlet Output wattage Series name Applications

- Blood glucose meter
- Blood pressure meter
- Nebulizer
- Inhaler
- · Portable medical device



GSM18B series

SPECIFICATION

| ORDER NO | | GSM18B05-P1J | GSM18B07-P1J | GSM18B09-P1J | GSM18B12-P1J | GSM18B15-P1J | GSM18B18-P1J | GSM18B24-P1J | GSM18B48-P1 | |
|------------------------------|---|---|---------------|--------------|-------------------|----------------|--------------|--------------|--------------|--|
| OUTPUT | SAFETY MODEL NO. | GSM18B05 | GSM18B07 | GSM18B09 | GSM18B12 | GSM18B15 | GSM18B18 | GSM18B24 | GSM18B48 | |
| | DC VOLTAGE Note.2 | 5V | 7.5V | 9V | 12V | 15V | 18V | 24V | 48V | |
| | RATED CURRENT | 3A | 2A | 2A | 1.5A | 1.2A | 1A | 0.75A | 0.375A | |
| | CURRENT RANGE | 0 ~ 3A | 0~2A | 0 ~ 2A | 0 ~ 1.5A | 0~1.2A | 0~1A | 0~0.75A | 0~0.375A | |
| | RATED POWER (max.) | 15W | 15W | 18W | 18W | 18W | 18W | 18W | 18W | |
| | RIPPLE & NOISE (max.) Note.3 | 60mVp-p | 80mVp-p | 80mVp-p | 120mVp-p | 120mVp-p | 150mVp-p | 180mVp-p | 240mVp-p | |
| | VOLTAGE TOLERANCE Note.4 | | ±5.0% | ±5.0% | ±3.0% | ±3.0% | ±3.0% | ±2.0% | ±2.0% | |
| | LINE REGULATION Note.5 | | ±1.0% | ±1.0% | ±1.0% | ±1.0% | ±1.0% | ±1.0% | ±1.0% | |
| | LOAD REGULATION | ±5.0% | ±5.0% | ±5.0% | ±3.0% | ±3.0% | ±3.0% | ±2.0% | ±2.0% | |
| | | 500ms, 30ms / 2 | | | 5VAC at full load | | | | | |
| | HOLD UP TIME (Typ.) | 16ms / 230VAC 16ms / 115VAC at full load | | | | | | | | |
| | | 80 ~ 264VAC 113 ~ 370VDC | | | | | | | | |
| INPUT | FREQUENCY RANGE | 47 ~ 63Hz | | | | | | | | |
| | EFFICIENCY (Typ.) | 80% | 83% | 84% | 85% | 85.5% | 86% | 87% | 88% | |
| | AC CURRENT (Typ.) | 0.5A / 115VAC | 0.25A/230\ | | 00,0 | 001070 | | 0.170 | 0070 | |
| | INRUSH CURRENT (Typ.) | 55A / 230VAC 30A / 115VAC | | | | | | | | |
| | LEAKAGE CURRENT(max.) | Touch current < 50//A/264VAC | | | | | | | | |
| PROTECTION | | 105 ~ 170% rated output power | | | | | | | | |
| | OVERLOAD | Protection type : Hiccup mode, recovers automatically after fault condition is removed | | | | | | | | |
| | | 5.25 ~ 7.5V | 7.88 ~ 10.13V | | 12.6 ~ 17.2V | 15.75 ~ 20.25V | | 25.2 ~ 32.4V | 50.4 ~ 64.8V | |
| | OVER VOLTAGE | | | | | | 10.0 24.00 | 20.2 02.47 | 00.4 04.07 | |
| ENVIRONMENT | WORKING TEMP. | Protection type : Shut down o/p voltage, re-power on to recover -25 ~ +60°C (Refer to "Derating Curve") | | | | | | | | |
| | WORKING HUMIDITY | 20% ~ 90% RH non-condensing | | | | | | | | |
| | STORAGE TEMP., HUMIDITY | -40 ~ +85°C, 10 ~ 95% RH | | | | | | | | |
| | TEMP. COEFFICIENT | ±0.03% /°C (0~40°C) | | | | | | | | |
| | VIBRATION | 10 ~ 500Hz, 2G 10min./1cycle, period for 60min. each along X, Y, Z axes | | | | | | | | |
| SAFETY & EMC (Note. 8) | SAFETY STANDARDS | ANSI/AAMI ES60601-1 / 60601-1-11, TUV EN60601-1 / 60601-1-11 approved | | | | | | | | |
| | WITHSTAND VOLTAGE | I/P-0/P:4KVAC | | | | | | | | |
| | ISOLATION RESISTANCE | I/P-O/P:100M Ohms / 500VDC / 25°C/ 70% RH | | | | | | | | |
| | EMC EMISSION | Compliance to EN55011(CISPR11) class B, EN61000-3-2,3, FCC PART 15 class B | | | | | | | | |
| | EMC IMMUNITY | Compliance to EN61000-4-2,3,4,5,6,8,11, EN55024, EN60601-1-2, EN61204-3 medical level, criteria A | | | | | | | | |
| OTHERS | MTBF | 796.7K hrs min. MIL-HDBK-217F(25°C) | | | | | | | | |
| | DIMENSION | 79*54*33mm (L*W*H) | | | | | | | | |
| | PACKING | 205g ; 60pcs / 13.3Kg / CARTON | | | | | | | | |
| CONNECTOR | PLUG | See page 3 : Other type available by customer requested | | | | | | | | |
| | CABLE | See page 3 ; Other type available by customer requested | | | | | | | | |
| NOTE | All parameters are specifie DC voltage: The output vol Ripple & noise are measur Tolerance: includes set up Line regulation is measure Length of set up time is me Derating may be needed u The power supply is consist EMC directives. For guidar | parameters are specified at 230VAC input, rated load, 25 [°] C 70% RH ambient. voltage: The output voltage set at point measure by plug terminal & 50% load. ple & noise are measured at 20MHz by using a 12" twisted pair terminated with a 0.1uf & 47uf capacitor. erance: includes set up tolerance, line regulation, load regulation. e regulation is measured from low line to high line at rated load. gth of set up time is measured at first cold start. Turning ON/OFF the power supply may lead to increase of the set up time. rating may be needed under low input voltage. Please check the derating curve for more details. e power supply is considered as an independent unit, but the final equipment still need to re-confirm that the whole system complies with the IC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." available on http://www.meanwell.com) | | | | | | | | |



18W AC-DC High Reliability Medical Adaptor

GSM18B series

